



Accessory Part No: 348585

GWM BONNET PROTECTOR 2020 - 2021 INSTALLATION INSTRUCTIONS

ACCESSORY PART NO: 348585

Installation Time: 30 min

Required to Fit

1x Bucket with soapy water
1x Philips head Screw driver

1x Pencil or non-permanent Marker

Warnings: Do not use automatic car wash.

Care Instructions: Clean item with mild detergent and water solution.
Do not use abrasive cleaners.

Precautions

Ensure that you adequately cover and protect seats, carpets, body parts as well as door entry areas with non-scratch covers, before installation. Ensure that your workmanship is of highest professional standard and that you do not scratch or damage the vehicle or accessory to be fitted.

Before commencing with fitment, carefully unwrap the product and ensure that the kit is complete and that the part is free of damage.

Outer brackets (Z)



3M plastic
tape
(X)



Metal
clips
(Y)





Access Points (A, B, C & D) for Chrome Cladding



Reference Picture For Mounting the four black brackets (Z)



Accessory Part No: 348585

Installation Instruction of GWM Bonnet Protector

1. Loosen up points A, B, C & D to loosen your front chrome cladding. Use a plastic trim remover to pop it loose.
2. Use the clear 3M plastic tape (X) to ensure that the metal does not scratch the body paint. For the 2 middle clips (Y), stick the tape onto the clip directly. For the outer clips, fold the tape around the edge of the bonnet with about 50-50 on top & bottom. Ensure that the metal clip (Y) & bolts only comes into contact with the clear 3M tape.
3. Take the screws out of point B & C and slide in the two flat metal clips (Y) with the forked end over those screws. Tighten B & C screws back up which will then hold the 2 metal clips tight.
4. Pop chrome cladding back into place and retighten all bolts (A&D)
5. Attach the bonnet protector using the 2 middle clips (Y) . This will help position the bonnet protector
6. Using a non-permanent marker, mark out where the outer brackets (Z) will sit by looking at the bonnet protector holes.
7. Mount the four black brackets (Z) Onto end each of the bonnet protector. Keep all bolts loose.