



UHF MICROPHONE BRACKET FOR TOYOTA HILUX (MAY 2020+) INSTALLATION INSTRUCTIONS

ACCESSORY PART NO: 530222 Installation Time: 10 min

Care Instructions:

Clean item with mild detergent and water solution.

Do not use abrasive cleaners

Warnings:

Please check all parts are complete according to the parts list prior to installation of the product. If parts are missing, please contact us as attempting to install an incomplete kit may void your warranty

We highly recommend that this product is installed by a professional fitter. Bosscoauto is not liable for damage to the vehicle or product due to installation error.

Recommended fitters:

Scan the following QR code to find our network of recommended fitters all over Australia. Book with them so they can do the hard work for you!

Disclaimer: These are all separate businesses to Bossco4x4 and we are not liable for their work








Parts List		
Item	Part Name	Qty
1	UHF Bracket	1
2	M3x16mm bolt	2
3	M3 Nut	2
4	Alcohol Pad	1
5	Adhesion promoter	1
6	Instructions	1









M







Step 1

Attach the microphone mount supplied by your UHF Radio manufacturer to the UHF mount using the M3 bolts and nuts supplied.



Step 2

Test fit the bracket onto the location show in the pictures below. DO NOT REMOVE THE BACKING PAPER FROM THE 3M TAPE AT THIS STAGE.

Step 3

Wipe the area where the bracket is to be installed thoroughly with the supplied alcohol wipe. Then wipe it dry completely.

Wipe the area where the bracket is to be installed thoroughly with the supplied adhesion promoter. Make sure to apply the promoter ONLY to the area where the tape will be installed. Allow promoter to dry.

Step 4

Remove the backing paper from the double-sided tape and carefully place the bracket on the location as shown in the pictures below. Once in place, apply firm pressure to the bracket for at least 20 seconds.

IMPORTANT: DO NOT HANG THE HANDPIECE/MICROPHONE FOR AT LEAST 72 HOURS.



