



BONNET PROTECTOR SUITABLE FOR NEXT GEN FORD RANGER 2022-ONWARDS

SKU: BP-RAN-01



Installation Guide

Please note:

Please read these instructions carefully prior to installation. Check the contents of this kit before commencing fitment and report any discrepancies. Do not use power tools. Only tighten with hand tools to avoid stripping the bolt heads or cross threading the bolts. Prior to commencing the installation it is the installers responsibility to verify that all components are correct. Problems and losses which occur due to improper installation and use are not covered by our warranty.



Step 1:

- Start by cleaning the surface.
- Place the bonnet protector onto the bonnet and mark the outer edge of the bonnet with a marker.
- Make sure that the bonnet protector is lined up evenly from left to right. (*See figure 1*)



Figure 1

Step 2:

- Remove the plastic clips that hold the rubber weather strip in place.



Figure 2

Step 3:

- Stick on the clear adhesive strips to the bonnet over the previously marked points. *(See figure 3)*



Figure 3

Step 4:

- Push the metal clips onto the bonnet over the adhesive strips.
- If the metal clips are not tight enough, they can be pressed together. This will help keep the clips clamped onto the bonnet.



Figure 4



Step 5:

→ Push the plastic inserts through the metal clips and place the rubber back on. *(See figure 5)*



Figure 5

Step 6:

→ Install the phillips head screws into the plastic inserts. *(See figure 6)*



Figure 6



Step 7:

- Place the washers over the hole on the outer side of the metal clips. *(See figure 7)*



Figure 7

Step 8:

- Place the bonnet protector onto the vehicle and line up the holes in the bonnet protector with the holes in the metal clips.
- Use a screwdriver to screw in the phillips-head bolts.



Figure 8



Step 9:

→ Close the screw cap. (See Figure 9)



Figure 9